



# EAGLE RENTAL™

Stevens: 1327 N. Reading Road, 17578 - (717) 336-0777  
Lebanon: 2530 Quentin Road, 17042 - (717) 274-3945  
www.eaglerentalcenter.com

## Single Slushy/Smoothie Machine Instructions (1-1/2 Gallons)



### Slushy Mixture

Mix one gallon of slushy syrup with four gallons of cold water (we recommend you use the 5-gallon bucket to mix and then pour mix into hopper). Hopper holds 1-1/2 gallons of slushy mix. Allow two hours for initial freezing time.

### Switches

1. There are two switches which operate the machine.
2. The first switch is the "on/off" switch. "0" position is "off" and "I" is "on".
3. The second switch controls the auger and refrigeration. "1" position is "Soft Drink Mode". "0" position is "off" and "II" Position is "Slushy Mode"

### Operating Machine

1. Set the Power Switch to "I" position.
2. Set the Auger/Refrigeration Switch to either "I" position for soft drinks or "II" Position for slushy.
3. If beverage seems too cold or too warm, turn it clockwise to decrease temperature or turn counterclockwise to increase temperature. **This will only adjust the temperature in soft drink mode. The slushy temperature is preset by the manufacturer.**

### Helpful Hints

- For best results, use indoors. Never in extreme heat.
- For a faster slushy time, pre-chill liquid refrigerator.

### CAUTION!

Never fill above the max fill line

Never let mixture go below minimum fill line when auger is turning or slush will turn back to liquid.

**Remember there will be an additional cleaning charge if the unit is not returned cleaned.** Empty the hopper. Turn off the machine and add one gallon of warm water to the hopper and drain. Repeat as many times as needed until hopper is clean.